



Fisher Quick Reference Guide (QRG)



What to do during the different stages of Fisher Operations

Page 3 - Pre-departure checks (in port)

Page 4 - During Fishing

Page 5 - Returning to Port

Page 6 - Last Trip of Month

Spark Support Service Desk - Phone 0800 225 674

Pre-departure checks in port (prior to fishing):



Step 1: TURN ON

Step 2: Check 'disk available' is above **70%**

Step 3: Check the connectivity is showing Spark

Step 4: Check the time is changing

Step 5: Check the cameras are clear and working

Step 6: Check GPS is showing result

Step 7: LEAVE SYSTEM ON - If any of these steps fail - Call 0800 225 674.





During fishing:

Step 1: Check the cameras are clear and working

Step 2: Check the time is changing

Step 3: Check GPS is showing result

Step 4: LEAVE SYSTEM ON.





Upon returning to port:

Step 1: Check if 'disk available' is less than **70%**. If **YES** – go to **Step 2**, If **NO** – go to **Step 5**

Step 2: Check connectivity to Spark network wait for upload to complete (once 'disk available' gets to **100%**)

Step 3: If disk availability doesn't increase, call Spark Support Service Desk **0800 225 674**

Step 4: If no Spark connectivity is available, call Spark Support Service Desk **0800 225 674**

Step 5: Switch monitoring system **stand by mode**.



Step 2

Step 1



Last trip of month:

Step 1: Check if 'disk available' is less than **100%**. If **YES** – go to **Step 2**, If **NO** – go to **Step 5**

Step 2: Check connectivity to Spark network wait for upload to complete (once 'disk available' gets to **100%**)

Step 3: If disk availability doesn't increase, call Spark Support Service Desk **0800 225 674**

Step 4: If no Spark connectivity is available, call Spark Support Service Desk **0800 225 674**

Step 5: Switch monitoring system to **stand by mode**.



Step 2

Step 1



Hanwha Fixed Dome IP Cameras

HARDWARE DIMENSIONS:

YellowFin 451 - 153mm (L) x 108mm (W) x 72mm (H), DC input 8-35V DC

Cameras - 137cm diameter x 106.1mm height

Display - 245mm x 166mm x 35mm

Antenna - 750mm length x 75mm diameter





Spark Support Service Desk - Phone 0800 225 674